

CARE AND MAINTENANCE OF NOCLAF WASHBASINS

1. In the first four weeks of use only water with liquid cleanser should be used for washing. Do not use any purifiers that contain abrasives, in any form (liquid or powder).
2. If there are any stains on the sink we recommend their removal to date. You should then use a damp cloth with a mild detergent such as dishwashing liquid. Clean doing circular movements
3. Product should not be cleaned with abrasive (Cif type milk, pumice, sand, etc.), as this may cause permanent damage to the surface and dulling sanitary layer.
4. Sink is sensitive to the following chemicals: sodium hydroxide, strong solvents, such as acetone, methanol, methylene chloride, potassium permanganate, etc.
5. Please take care so, the lasting settlement of the so-called limestone not arise. We suggest removal of formed sediment with diluted vinegar or other chemicals designed for this purpose.
6. You should also take care of the maintenance of the plate - masking the drain. You should do this at least once a week to clean the underside of the plate and the place the product surface is in contact with the plate.
7. The water temperature must not exceed 65 ° C.
8. For the wellbeing of the sink, it is advisable to polish every two months using generally available resources for polishing car body (such as car wax). This measure removes all traces of dirt and helps to keep the sink clean.

! **Note! Hair dye and other "colorful" cosmetics may leave minimal discoloration if they are not removed immediately from the surface of the sink.**

